


Four-Slot Terminal Cradle

-WD200-



Quick Start Guide

V1.0

Package

Please make sure the following contents are in the gift box. If something is missing or damaged, please contact your unitech representative.

The package contents


- WD200 Four-slot Terminal Charging Cradle
- Power Supply(5V/ 6A) without power cord

Optional accessories

- US power cord (P/N#1010-601551G)
- EU power cord (P/N#1550-602333G)
- UK power cord (P/N#1550-602689G)

Power connection


- 1) Plug the AC power cord into the power jack on the power adapter.
- 2) Plug the other end of the AC adapter into an electrical outlet.
- 3) Plug the power adapter cable into the DC in port of the cradle.



Charging Terminals with the cradle


You can charge up to four terminals at one time.

- 1) Be sure the cradle is connected to a power source.
- 2) Slide the terminal into the cradle.
- 3) The cradle will automatically detect the presence of the terminal and begin charging.



Checking the LED status

■ Charging only cradle	
Power LED	Description
Red Light	Power supply is connected



Power LED

- CAUTION!**
- To ensure the unit working properly, please keep all connectors away from the contaminants staying inside of them such as dust, grease, mud, and water. The negligence may cause the unit with no communication, short circuited, overheated and so on.
 - If the connector is damaged, please ensure the connector is being fully repaired before using the unit to avoid causing short circuited.



<http://www.ute.com/>